



INDUSTRIAL FILTER & PUMP MFG. CO.

2680 US Hwy 1, Mims, FL 32754

Phone: (708) 656 – 7800 ♦ sales@industrialfilter.com

www.industrialfilter.com

1-1/2" REPLACEABLE LEAF INSERT INSTALLATION GUIDE

1. Lightly grease threads and place insert into threaded hole on discharge manifold.
2. Tighten until underside of hex is flush with surface of manifold, preferably using a 2" twelve-point socket to prevent damage to the hex edges, however a wrench can be used as well. Edges must be protected to ensure inserts can be easily removed in the future.



Figure A | Threaded holes on manifold



Figure B | Inserts after being installed in manifold